



- NOTE: 1. FOR DEVICE FUNCTIONS SEE APPROPRIATE DEVICE TEMPLATES.
 2. SEE DEVICE TEMPLATE FOR MOUNTING HOLE LOCATIONS.
 3. A COORDINATOR MUST BE USED ON THE INACTIVE DOOR.

1609 Strike Application for 2227 Vertical Rod & 22 Rim Devices (Panic Device Only)

VON DUPRIN®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER:

30244_a

DATE:
05-28-13