

# Schlage **Artus**

## Manual setup instructions

Enter the programming sequence below on the keypad of the Schlage Artus lock to manually change the default admin code. Once set, the lock will no longer voice prompt to pair the lock to a mobile device.

### 1. Enter




### 2. Enter



### 3. Enter



### 4. Repeat



### IMPORTANT: Note for the homeowner

If your lock was installed by someone other than yourself, we highly recommend you complete a factory reset on the lock to ensure all previously set PIN codes are successfully deleted.

1. Remove the battery cover and hold down the reset button for 4 seconds.
2. The lock will prompt, "Please enter initialisation passcode". Enter 000# on the keypad.
3. The lock will prompt, "Deleting administrator successful" indicating that the reset procedure is complete.
4. The lock is now available to be paired with a mobile device using the Schlage Breeze app.
5. Use the Schlage Breeze app to set up your lock, scan the QR code below to download the app.



**App Store**



**Play Store**

ALLEGION (NEW ZEALAND) LIMITED

Freephone 0800 477 869  
Email nzinfo@allegion.com  
www.allegion.co.nz